

## PCX NODE ID CONVERSION



HEX	DEC	1	2	3	4	5	6	7	8
01	1								X
02	2							X	
03	3							X	X
04	4						X		
05	5						X		X
06	6						X	X	
07	7						X	X	X
08	8					X			
09	9					X			X
0A	10					X		X	
0B	11					X		X	X
0C	12					X	X		
0D	13					X	X		X
0E	14					X	X	X	
0F	15					X	X	X	X
10	16				X				
11	17				X				X
12	18				X			X	
13	19				X			X	X
14	20				X		X		
15	21				X		X		X
16	22				X		X	X	
17	23				X		X	X	X
18	24				X	X			
19	25				X	X			X
1A	26				X	X		X	
1B	27				X	X		X	X
1C	28				X	X	X		
1D	29				X	X	X		X
1E	30				X	X	X	X	
1F	31				X	X	X	X	X
20	32			X					
21	33			X					X
22	34			X				X	
23	35			X				X	X
24	36			X			X		
25	37			X			X		X
26	38			X			X	X	
27	39			X			X	X	X
28	40			X		X			
29	41			X		X			X
2A	42			X		X		X	
2B	43			X		X		X	X
2C	44			X		X	X		
2D	45			X		X	X		X
2E	46			X		X	X	X	
2F	47			X		X	X	X	X

X - switch is in the up position, turned on.

## PCX NODE ID CONVERSION



30	48			X	X				
31	49			X	X				X
32	50			X	X			X	
33	51			X	X			X	X
34	52			X	X		X		
35	53			X	X		X		X
36	54			X	X		X	X	
37	55			X	X		X	X	X
38	56			X	X	X			
39	57			X	X	X			X
3A	58			X	X	X		X	
3B	59			X	X	X		X	X
3C	60			X	X	X	X		
3D	61			X	X	X	X		X
3E	62			X	X	X	X	X	
3F	63			X	X	X	X	X	X
40	64		X						
41	65		X						X
42	66		X					X	
43	67		X					X	X
44	68		X				X		
45	69		X				X		X
46	70		X				X	X	
47	71		X				X	X	X
48	72		X			X			
49	73		X			X			X
4A	74		X			X		X	
4B	75		X			X		X	X
4C	76		X			X	X		
4D	77		X			X	X		X
4E	78		X			X	X	X	
4F	79		X			X	X	X	X
50	80		X		X				
51	81		X		X				X
52	82		X		X			X	
53	83		X		X			X	X
54	84		X		X		X		
55	85		X		X		X		X
56	86		X		X		X	X	
57	87		X		X		X	X	X
58	88		X		X	X			
59	89		X		X	X			X
5A	90		X		X	X		X	
5B	91		X		X	X		X	X
5C	92		X		X	X	X		
5D	93		X		X	X	X		X
5E	94		X		X	X	X	X	
5F	95		X		X	X	X	X	X

X - switch is in the up position, turned on.

## PCX NODE ID CONVERSION



60	96		X	X					
61	97		X	X					X
62	98		X	X				X	
63	99		X	X				X	X
64	100		X	X			X		
65	101		X	X			X		X
66	102		X	X			X	X	
67	103		X	X			X	X	X
68	104		X	X		X			
69	105		X	X		X			X
6A	106		X	X		X		X	
6B	107		X	X		X		X	X
6C	108		X	X		X	X		
6D	109		X	X		X	X		X
6E	110		X	X		X	X	X	
6F	111		X	X		X	X	X	X
70	112		X	X	X				
71	113		X	X	X				X
72	114		X	X	X			X	
73	115		X	X	X			X	X
74	116		X	X	X		X		
75	117		X	X	X		X		X
76	118		X	X	X		X	X	
77	119		X	X	X		X	X	X
78	120		X	X	X	X			
79	121		X	X	X	X			X
7A	122		X	X	X	X		X	
7B	123		X	X	X	X		X	X
7C	124		X	X	X	X	X		
7D	125		X	X	X	X	X		X
7E	126		X	X	X	X	X	X	
7F	127		X	X	X	X	X	X	X
80	128	X							
81	129	X							X
82	130	X						X	
83	131	X						X	X
84	132	X					X		
85	133	X					X		X
86	134	X					X	X	
87	135	X					X	X	X
88	136	X				X			
89	137	X				X			X
8A	138	X				X		X	
8B	139	X				X		X	X
8C	140	X				X	X		
8D	141	X				X	X		X
8E	142	X				X	X	X	
8F	143	X				X	X	X	X

X - switch is in the up position, turned on.

## PCX NODE ID CONVERSION



90	144	X			X				
91	145	X			X				X
92	146	X			X			X	
93	147	X			X			X	X
94	148	X			X		X		
95	149	X			X		X		X
96	150	X			X		X	X	
97	151	X			X		X	X	X
98	152	X			X	X			
99	153	X			X	X			X
9A	154	X			X	X		X	
9B	155	X			X	X		X	X
9C	156	X			X	X	X		
9D	157	X			X	X	X		X
9E	158	X			X	X	X	X	
9F	159	X			X	X	X	X	X
A0	160	X		X					
A1	161	X		X					X
A2	162	X		X				X	
A3	163	X		X				X	X
A4	164	X		X			X		
A5	165	X		X			X		X
A6	166	X		X			X	X	
A7	167	X		X			X	X	X
A8	168	X		X		X			
A9	169	X		X		X			X
AA	170	X		X		X		X	
AB	171	X		X		X		X	X
AC	172	X		X		X	X		
AD	173	X		X		X	X		X
AE	174	X		X		X	X	X	
AF	175	X		X		X	X	X	X
B0	176	X		X	X				
B1	177	X		X	X				X
B2	178	X		X	X			X	
B3	179	X		X	X			X	X
B4	180	X		X	X		X		
B5	181	X		X	X		X		X
B6	182	X		X	X		X	X	
B7	183	X		X	X		X	X	X
B8	184	X		X	X	X			
B9	185	X		X	X	X			X
BA	186	X		X	X	X		X	
BB	187	X		X	X	X		X	X
BC	188	X		X	X	X	X		
BD	189	X		X	X	X	X		X
BE	190	X		X	X	X	X	X	
BF	191	X		X	X	X	X	X	X

X - switch is in the up position, turned on.

## PCX NODE ID CONVERSION



C0	192	X	X						
C1	193	X	X						X
C2	194	X	X					X	
C3	195	X	X					X	X
C4	196	X	X				X		
C5	197	X	X				X		X
C6	198	X	X				X	X	
C7	199	X	X				X	X	X
C8	200	X	X			X			
C9	201	X	X			X			X
CA	202	X	X			X		X	
CB	203	X	X			X		X	X
CC	204	X	X			X	X		
CD	205	X	X			X	X		X
CE	206	X	X			X	X	X	
CF	207	X	X			X	X	X	X
D0	208	X	X		X				
D1	209	X	X		X				X
D2	210	X	X		X			X	
D3	211	X	X		X			X	X
D4	212	X	X		X		X		
D5	213	X	X		X		X		X
D6	214	X	X		X		X	X	
D7	215	X	X		X		X	X	X
D8	216	X	X		X	X			
D9	217	X	X		X	X			X
DA	218	X	X		X	X		X	
DB	219	X	X		X	X		X	X
DC	220	X	X		X	X	X		
DD	221	X	X		X	X	X		X
DE	222	X	X		X	X	X	X	
DF	223	X	X		X	X	X	X	X
E0	224	X	X	X					
E1	225	X	X	X					X
E2	226	X	X	X				X	
E3	227	X	X	X				X	X
E4	228	X	X	X			X		
E5	229	X	X	X			X		X
E6	230	X	X	X			X	X	
E7	231	X	X	X			X	X	X
E8	232	X	X	X		X			
E9	233	X	X	X		X			X
EA	234	X	X	X		X		X	
EB	235	X	X	X		X		X	X
EC	236	X	X	X		X	X		
ED	237	X	X	X		X	X		X
EE	238	X	X	X		X	X	X	
EF	239	X	X	X		X	X	X	X

X - switch is in the up position, turned on.

## PCX NODE ID CONVERSION



F0	240	X	X	X	X				
F1	241	X	X	X	X				X
F2	242	X	X	X	X			X	
F3	243	X	X	X	X			X	X
F4	244	X	X	X	X		X		
F5	245	X	X	X	X		X		X
F6	246	X	X	X	X		X	X	
F7	247	X	X	X	X		X	X	X
F8	248	X	X	X	X	X			
F9	249	X	X	X	X	X			X
FA	250	X	X	X	X	X		X	
FB	251	X	X	X	X	X		X	X
FC	252	X	X	X	X	X	X		
FD	253	X	X	X	X	X	X		X
FE	254	X	X	X	X	X	X	X	
FF	255	X	X	X	X	X	X	X	X